CASE IH 1020 FLEX HEAD

GRAIN PLATFORM AUGER LINER INSTRUCTIONS

PLEASE REFER TO YOUR COMBINE MANUFACTURER'S OPERATORS MANUAL FOR PERTINENT SAFETY PRECAUTIONS

IMPORTANT: READ ENTIRE INSTRUCTION SHEET BEFORE BEGINING INSTALLATION

- 1. REMOVE BOTTOM SHEETS (FIGURE 1)
- 2. RAISE BOTH ENDS OF AUGER SO THERE IS APPROXIMATELY 1/2" BETWEEN THE TROUGH AND AUGER FLIGHTING. CLEAN ALL CROP RESIDUE AND DEBRIS FROM THE AUGER TROUGH.
- 3. STARTING WITH THE CENTER PANEL, LAY OUT PANELS TO DETERMINE POSITION OF EACH PANEL. END PANELS MAY NEED TO BE TRIMMED TO FIT.
- 4. INSTALL AUGER LINER STARTING WITH THE CENTER PANEL. CENTER THE PANEL BY MEASURING FROM EACH END OF THE TROUGH.
- 5. ALIGN LEADING EDGE OF PANEL WITH FRONT EDGE OF THE AUGER FLOOR.
- 6. WITH THE PANEL POSITIONED CORRECTLY LEAVING ABOUT A 3/16" GAP BETWEEN PANELS TO ALLOW FOR EXPANSION/CONTRACTION OF PANELS, WEDGE THE PANEL TIGHT AGAINST THE AUGER FLOOR USING THE INCLUDED SHIMS. (FIGURE 2)
- 7. DRILL AND RIVET ALONG THE LEADING EDGE EVERY 6 TO 8 INCHES AND 10 TO 12 INCHES ALONG THE REAR EDGE. (FIGURE 3)
- 8. REPEAT STEPS 5 THRU 7 TO INSTALL LEFT AND RIGHT PANELS.
- RE-INSTALL BOTTOM SHIELDS.





FIGURE 2

CAUTION

ENGAGE REEL LIFT CYLINDER SUPPORTS AND HEADER LIFT CYLINDER STANDS BEFORE WORKING AROUND OR UNDER A RAISED REEL OR HEADER

NOTES:

-POLY LINER AND HEADER SHOULD BE AT 70° F OR ABOVE FOR EASE OF INSTALLATION AND SMOOTH FIT -AUGER CAN BE REMOVED FOR INSTALLATION OR THE DRIVE DISCONNECTED SO IT CAN BE TURNED EASILY




FIGURE 3



120 Eastgate Drive SE Hutchinson, MN 55350

1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM



(VIEW FROM OPERATORS POSITION LOOKING DOWN ONTO HEAD)



120 Eastgate Drive SE **Hutchinson, MN 55350** 1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM