

Corn Shield Mounting Instructions

Harvest Tec Poly Head

1. Position the Corn Shield on the poly fender for best fit.
2. Once in position, mark around the base of the Corn Shield.
3. Measures the locations of nuts molded into the Corn Shield and transfer them to the poly fender.
4. Drill a 3/8" hole for the front mounting on top of the fender.
5. Drill (2) 3/8" holes for the rear mounting studs perpendicular to the poly.
6. Screw the (3) 5/16" x 1½" threaded rods into the back nuts and into the front nut of the Corn Shield.
7. Place Corn Shield on the point.
8. Use the fender washers and nuts provided to secure the Corn Shield on the point.
9. The rubber flap will need to be trimmed to lay flat on the snout and not contact any moving parts.
Raise point up as high as you can to select area you need to remove from flap.



MAY WES
Original Poly People
A DIVISION OF PRIDE SOLUTIONS

120 Eastgate Drive SE
PO Box 7
Hutchinson, MN 55350

1-800-788-6483
1-320-587-2322
1-320-587-6112 (Fax)

WWW.MAYWES.COM