Case IH 1660-2588 Tank Fill Tube Liner Installation Instructions

Please read the entire instruction sheet before begining installation.

Please refer to your combine manufacturer's operators manual for pertinent safety precautions.

- 1. Remove auger bearing mounting bracket and remove auger from housing.
- 2. Remove any debris from inside the auger housing.
- 3. Insert the Tube Liner into the tank fill tube.
- 4. Position the top edge of the Tube Liner flush with the top edge of the tank fill tube (see Figure 1.0).
- 5. Snap the two edges of the liner together by pushing the liner toward the tank fill tube walls and pressing along the seam. A putty knife can also be used to help snap the seams together (see Figure 2.0).
- 6. Verify that the liner is rotated to the correct position and the bottom edge is flush with the tank fill tube (see Figures 1.0 & 2.0).
- 7. Clamp liner to the tube to ensure it does not move (see Figures 1.0 & 2.0).







120 Eastgate Drive SE PO Box 7 Hutchinson, MN 55350 1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM

Case IH 1660-2588 Tank Fill Tube Liner Installation Instructions

Please read the entire instruction sheet before begining installation.

Please refer to your combine manufacturer's operators manual for pertinent safety precautions.

- 8. Using supplied 13/64" drill bit and rivets, drill and rivet 1/2" from the seam and spaced every 4" along both sides of the seam (see Figure 3.0).
- 9. Drill and rivet the outer lower half of the fill tube, and the upper inside edge of the fill tube as shown (see Figures 5.0 & 6.0).
- 10. Reinstall auger housing, auger, and bearing mounting bracket and verify clearance prior to operation. Adjust to provide proper clearance as required.











120 Eastgate Drive SE PO Box 7 Hutchinson, MN 55350 1-800-788-6483 1-320-587-2322 1-320-587-6112 (Fax)

WWW.MAYWES.COM