

Corn Shield Mounting Instructions

Utilizing Threaded Rod

1. Position the Corn Shield on the poly point for best fit.
2. Once in position, mark around the base of the Corn Shield.
3. Measure the locations of nuts molded into the Corn Shield and transfer them to the poly point.
4. Drill 3/8" hole for the front mounting stud on top and drill 3/8" hole in the bottom side of the point approximately 7" from the plug. (Make sure when assembled, the nut and washer do not hit on the point height support).
5. Drill through the bottom to enable the front threaded rod to be fed through from the top and out the bottom.
6. Drill (2) 3/8" holes all the way through for the rear mounting studs perpendicular to the poly.
7. Screw the (2) 5/16" x 2½" threaded rods into the back nuts and the 5/16" x 9" threaded rod into the front nut of the Corn Shield.
8. Place Corn Shield on the point.
9. Use the fender washers and nuts provided to secure the Corn Shield on the point.
10. The rubber flap will need to be trimmed to lay flat on the snout and not contact any moving parts.

Raise point up as high as you can to select area you need to remove from flap.



MAY WES
Original Poly People
A DIVISION OF PRIDE SOLUTIONS

120 Eastgate Drive SE
PO Box 7
Hutchinson, MN 55350

1-800-788-6483
1-320-587-2322
1-320-587-6112 (Fax)

WWW.MAYWES.COM